



Description: LED Taillight  
Part Number: 311139 - 311145 - 311147  
Application: 09-2013 Ford F-150



Tools needed  
8mm Socket and Ratchet



Remove the two 8mm bolts  
holding the taillights in.



Pull the taillight outward .



Remove the light sockets by  
twisting and pulling outward.



Be sure to clean the pockets so  
the resistor will adhere to the  
vehicle.



Remove the stock 3157 light  
bulbs from the sockets by  
pulling straight out.



Peel the backing off of the resistors  
and place them in the open  
pockets out of the way. Pressing  
firmly against the vehicle.



Plug the 3157 pigtail coming from  
the taillight into the light socket.  
Be sure to match the black wires  
from the taillight and the socket  
on the same side.



Install the taillight back onto the  
vehicle.



Be sure to check all functions  
before operating on the highway.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.