



5150 Eucalyptus Ave. Unit A. Chino, CA 91710
(888) 360-3696 • techsupport@anzousa.com • ANZOUSA.COM

PRODUCT DESCRIPTION: 3rd Brake light
APPLICATION: 2015-2018 Chevrolet Colorado



INSTALLATION GUIDE

READ COMPLETE INSTRUCTIONS BEFORE INSTALLATION
Improper installation may void warranty.



TOOLS NEEDED: T15 Torx bit

STEP 1



Factory 3rd brake light

STEP 2



Remove two T15 torx screws.

STEP 3



Remove factory 3rd brake light. Disconnect main connector.

STEP 4



Connect Anzo USA 3rd brake light to main harness.

STEP 5



Slide Anzo USA 3rd brake light into opening then tighten T15 torx screws by hand. *Do not over tighten*

STEP 6



Test all functions of light before operating vehicle.