


2021-2023 FORD F-150  
HEADLIGHTS  
TOTAL STEPS: 10



**STEP 1**  
LOCATE DRL HARNESS  
PROVIDED WITH HEADLIGHTS  
IN BOX.




**STEP 2**  
CONNECT DRL HARNESS  
CONNECTOR CIRCLED TO  
DRIVER/LEFT SIDE HEADLIGHT  
DRL CONNECTOR AS SHOWN.



**STEP 3**  
CONNECT DRL HARNESS  
CONNECTOR TO  
PASSENGER/RIGHT SIDE  
HEADLIGHT DRL CONNECTOR.



**STEP 4**  
LOCATE VEHICLE BATTERY ON  
PASSENGER/RIGHT SIDE OF  
VEHICLE.



**STEP 5**  
CONNECT FORK SPADE  
CONNECTORS TO THE  
BATTERY.  
RED WIRE GOES TO POSITIVE  
(+) SIDE OF BATTERY.  
BLACK WIRE GOES TO  
NEGATIVE(-) SIDE OF BATTERY.



**STEP 6**  
AFTER CONNECTING DRL  
HARNESS TO BATTERY, ROUTE  
AND SECURE DRL HARNESS  
FROM BATTERY TO VEHICLE  
WITH PROVIDED ZIP TIES.



**STEP 7**  
LOCATE THE BUTTON SWITCH ON THE TOP  
BULB COVER OF THE HEADLIGHT.  
THERE IS A STICKER INDICATING THE  
WHITE/AMBER RUNNING LIGHT/DRL MODE.  
  
DO NOT REMOVE RUBBER COVER FROM  
HEADLIGHT!



**STEP 8**  
PRESS THE "WHITE" BUTTON  
WITHOUT REMOVING RUBBER  
COVER AND RUNNING  
LIGHT/DRL WILL BE WHITE  
COLOR AS SHOWN.



**STEP 9**  
PRESS THE "AMBER" BUTTON  
WITHOUT REMOVING RUBBER  
COVER AND RUNNING  
LIGHT/DRL WILL BE AMBER  
COLOR AS SHOWN.



**STEP 10**  
TEST ALL FUNCTIONS OF  
HEADLIGHTS BEFORE DRIVING  
ON THE ROAD.